

OXFORD PRESENCE (Spare Parts)

NO	PART NUMBER	ENABLE PART NUMBER	DESCRIPTION	QTY
1	0Y0066	SH1020	100mm rear castor (braked)	2
2	0Y0263	SH1830	Straight-line steering device	1
3	0Y0073	SH1018	100mm front castor (non-braked) (inc. load bearing washer and tightening wrench - wrench not shown)	2
4	0Y0082	SH1496	Mast extrusion (inc. labels) (OXF-PRESENCE models only)	1
	0YJH009390	SH1500	Mast extrusion (OXF-PRESENCE-S models only)	1
5	0Y0083	SH1128	Boom extrusion (inc. boom end caps and labels, except product name label)	1
6	0Y0084	SH1692	Push handle assembly (inc. fixings)	1
7	0Y0089	SH1158	Casted boom to mast pivot joint (inc. connection bolts/fixings/spacers)	1
8	0Y0048	HA1031	Spreader bar assembly complete (6-point) *	1
9	0Y0050	HA1019	Cradle assembly complete (4-point) *	1
10	0Y0080	SH1066	Base assembly (inc. base casting, bottom plate and labels, not internal parts)	1
11	0Y0085	SH1388	Left leg extrusion (inc. fixings)	1
12	0Y0086	SH1736	Right leg extrusion (inc. fixings)	1
-	39001310	SH1452	Low legs kit (not shown)	1
13	39001370	SH1228	Control box (Smart™ Monitor)	1
	0Y0074	SH1230	Control box (Standard)	1
14	0Y0067	SH1102	Battery pack *	1
15	39001309	SH1858	User handset (Smart™ Monitor only)	1
	0Y0075	SH1860	User handset (Standard control box)	1
-	39001368	SH1152	Calibration handset (Smart™ Monitor only) (not shown)	1
-	39001369	SH1058	Actuator reset handset (Smart™ Monitor only) (not shown)	1
16	39001316	SH1798	Smart™ Monitor retrofit kit (inc. control box, battery and user handset)	1
17	0Y0053	SH1174	Charger and stand assembly (without charger lead)	1
18	0Y0071		Charger lead (UK)	1
19	0Y0072		Charger lead (EU)	1
-	0Y0730	SH1178	Charger lead (AU)	1
20	0Y0087	SH1042	Actuator (LA34) - 400mm stroke (inc. location pins, sleeves, washers, circlips and labels) (OXFPRESENCE models only)	1
	11014708	SH1044	Actuator (LA44) - 400mm stroke (inc. location pins, sleeves, washers, circlips and labels) (OXFPRESENCE-S models only) (not shown)	1
-	39001314	SH1050	Actuator fixing kit (OXF-PRESENCE-S models only) (not shown)	1
-	11013922	SH1056	Actuator (LA44) power lead (not shown)	1
21	0Y0069	SH1092	Battery and controller bracket (inc. fixings)	1
22	0Y0081	SH1414	Leg opening actuator - 30mm stroke (inc. bolts and fixings)	1
23	0Y0126	SH1660	Pivot caps	2
24	0Y0088	SH1294	Fixings kit (all bolts, screws and fixings)	1
25	0Y0077	SH1524	Mast to base electrical connection kit (inc. wires)	1
-	0Y0129	SH1086	Base to actuator electrical connection kit (inc. wires) (not shown)	1
26	0Y0078	SH1314	Foot push pad assembly complete	2
27	0Y0079	SH1512	Mast locking knob assembly (inc. plastic base insert)	1
28	0Y0108	SH1140	Boom to mast pivot plastic caps	2
29	0Y0076	SH1520	Mast side caps	2
30	0YJH009400	SH1700	Quick release pin kit	1
31	0Y0380	SH1814	Spreader bar washer and o-ring spares kit	1
32	0Y0728	SH1116	Boom end plastic cap	1
33	11015567	SH1148	Bushing anti-friction for king pin (After March 2015)	2
-	0Y0128	SH1164	Castor tightening wrench (not shown)	1
-	0Y0091	SH1260	Decal set (exc. serial number labels) (not shown)	1
-	0Y0070	SH1348	Handset clip (not shown)	2

OXFORD PRESENCE (Spare Parts)

